



CCPS21

CC121 / CC171 / CC221 / CC321

  **250 kg MAXI**





Fixer la machine au Sol
Set the machine to the ground
Legen Sie den Maschine-Boden
Establecer el terreno de la máquina
Impostare il terreno della macchina

